User Manual

AdvanceCommunicator™
Verizon® V860 BARRAGE
Part No. AT3064A

The AdvanceTec *AdvanceCommunicator™ is an* accessories designed to adapt the Verizon® V860 BARRAGE portable for convenient communication use in the home or office.

Verizon® is the registered trade mark of VerizonWireless®

Features:

- Hands-free operation for both Push-to-Talk (PTT) and phone calls
- Handset operation for both PTT and phone calls
- Rapid Charging facility
- Recording facility for both PTT and portable calls

Setting up the AT3064A AdvanceCommunicator™

1. Place the AdvanceCommunicator™ in a convenient position in your home or office within easy reach of an AC power outlet.
2. Attach the plug at the end of the coil cord of the Privacy Handset into the corresponding Plug on the back of the AdvanceCommunicator™.
3. Plug the power supply into a wall AC power outlet and the round barrel plug at the end of the cord of the power supply into the corresponding plug on the back of the AdvanceCommunicator™ At this point the LED will light.

<u>Installing the portable into the *AdvanceCommunicator*™</u>

1. Remove the rubber protective cover from the connector receptacle covering the micro USB connector on the left side of the handset (handset facing you) and align the micro USB connector at the end on the one cable from the left side of the AdvanceCommunicator and insert the connector into the portable.

2. Remove the rubber protective cover from the connector receptacle covering the audio connector on the right side of the handset (handset facing you) and align the pin connector at the end of the other cable from the back of the AdvanceCommunicator and insert the connector into the portable.
3. Insert the portable into the cradle by aligning the groove at the bottom of the handset with the ridge on the cradle and press the top of the handset back into the Cradle until it snaps into place.
4. Turn the portable on.
5. To remove the portable from the Cradle, press the release button on the top of the cradle.

Making and Receiving calls in Hands Free Mode.

1.To make a call in Hands-free mode, dial the desired number on the portable keypad and press SEND/GREEN BUTTON. Speak towards the Microphone indicated above.
2. The voice of the person you are calling will be heard via the built-in speaker in the *AdvanceCommunicator*™
3. To receive a call in Hands-free mode, either open the portable's flip cover or press shortly on the PTT/Space bar and speak towards the Microphone. The caller's voice will be heard via the built-in speaker in the *AdvanceCommunicator*™
4. To end a call in hands-free mode press the END button on the portable or close the portable flip cover.

Making and Receiving calls via the Portable.

1. To make a call using the AdvanceCommunicator™ Privacy Handset, dial the desired number on the portable keypad and press SEND/GREEN button. Lift and use the privacy handset as you would with a regular desktop phone.
3. To switch from a privacy handset call to hands-free call, place the privacy handset into its cradle on the AdvanceCommunicator™
2. To receive a call with the privacy handset, lift the privacy handset and press any button on the portable keypad or open the portable's flip cover. Use the handset as you would with a regular desktop phone.
3. To end a call while using the handset, place the handset back into the cradle and press the END/RED button, or merely close the portable's flip cover.

Use of the *AdvanceCommunicator*™ with Dispatch calls

1. To answer a dispatch call in Hands-free mode, press and hold down the PTT/Space Bar and speak towards the Microphone.

2. To answer a dispatch call using the privacy handset, pick up the privacy handset, press and hold down the round PTT button on the privacy handset and speak into the privacy handset as you would with a regular desktop phone.
3. To hear the other party in a dispatch call, release the PTT/Space bar (in Hands-free mode) or the round PTT handset button if using the Handset

Volume Control

The volume of the AdvanceCommunicator™ can be increased or lowered with the volume buttons on the portable

Recording Feature

1. The AdvanceCommunicator™ will allow the recording of audio traffic with an external recording device via a 3.5mm plug.
2. Dispatch calls will be recorded both audio in and audio out.
3. Portable calls will be recorded audio-in only.

Charging the battery

With the portable turned off, the *AdvanceCommunicator*™ will charge the battery to 60% in approximately 1 hour. The charge time will be longer if the portable is operational during charge time.

NOTE: Batteries of the portable will charge within the temperature window of -10 C to +40 C (50 F to 104 F). If the battery is outside this temperature window, no charge current will be supplied to the battery.

ADVANCETEC INDUSTRIES INC
1150 NW 163rd Drive, Miami, FL 33169
T: 305-623-3939 – F: 305-623-3996